



Getting started with your new LifeBook® B Series notebook


This convenient guide will lead you through the start-up process and will also offer some valuable tips.




Right Panel



Left Panel



Back Panel



Quick Tips

It takes approximately 3.0 hours to charge a single notebook battery, whether the notebook is turned off, in suspended mode, or in use.

Optimizing Battery Life

- Set power management setting to Maximize Battery Life.
- Adjust display brightness levels to lowest comfortable setting.
- Remove the PC Card when not needed.
- Utilize Suspend mode when not using your notebook.
- Read the Power Management section in your User's Guide for additional features.

Adjusting display brightness

- Fn + F6 to decrease brightness
- Fn + F7 to increase brightness

Adjusting volume

- Fn + F8 to decrease volume
- Fn + F9 to increase volume

1. What's in the Box

Check to see that all of the following are in the box:

- ☐ LifeBook notebook
- ☐ Lithium ion battery (installed)
- ☐ AC adapter with power cord
- ☐ Stylus
- ☐ Phone/modem (RJ-11) telephone cable
- ☐ Drivers and Applications Restore CD
- ☐ User's Guide
- ☐ Microsoft associated product materials
- ☐ International Terms and Conditions Booklet and Product Registration Card
- ☐ Restore DVD
- ☐ Trusted Platform Module (TPM) driver and application CD

Depending upon your configuration, the following items may also be shipped with your notebook:

- ☐ Additional lithium ion main battery
- ☐ Port Replicator
- ☐ External USB floppy disk drive
- ☐ Bluetooth driver CD
- ☐ Softex OmniPass CD

2. Turn on Your Notebook

- Plug the AC adapter into your notebook.
- Plug the power cord into the AC adapter.
- Connect the power cord to an electrical outlet.
- Connect phone cord or ethernet cable to your notebook and to a wall jack.
- Press the power button to turn on the notebook.
- The notebook is now on and the battery is charging.
- The notebook will begin a power-on self test. Once successfully completed, the operating system will begin the initialization process.

3. Register

- Enter the information as prompted to personalize your notebook, and configure your modem to dial.
- Register your notebook with Fujitsu Service and Support via our Web site at us.fujitsu.com/computers



4. Calibrate the Touch Screen

- Select the Fujitsu Touch Screen Calibration utility in the control panel
- Using the stylus, firmly touch and briefly hold at the center of the red target [+]. Lift the stylus from the screen and the target will move to a different location on the screen.
- Repeat for each of the nine target [+] points
- Finish the calibration produced by clicking the [update] button

! Screen should only be touched with stylus

5. Activate Additional Utilities

If you have the wireless LAN model, please ensure the wireless LAN ON/OFF switch is "on" before clicking the "click me" icon.

- Click the  icon on the desktop or in the start menu to activate additional utilities.
- Right click the Fujitsu Driver Update (FDU)  icon and follow the on-screen instructions to update your drivers. For more information, see your User's Guide.

Status Display Panel



Following are some common indicators.



Power
Steady: On
Blinking: Suspend Mode



AC Adapter
Steady: Adapter is Active



Battery Charging



Wireless Access
Steady: In Use



Hard Drive Access
Steady: In Use



PC Card Access
Steady: In Use



PC Card Access
Steady: In Use



Number Lock
Visible: In Use



Caps Lock
Visible: In Use



Scroll Lock
Visible: In Use



Security Indicator
Visible: Enter Password

Popular Accessories

Memory modules

- 256 MB SDRAM, DDR2 400
- 512 MB SDRAM, DDR2 400
- 1 GB SDRAM DDR2 400

Port replicator

External USB floppy drive

External USB CD-ROM drive

External DVD/CD-RW combo drive

Additional Lithium ion Battery (6-cell)

Auto/Airline adapter

Additional AC adapter

Battery charger

Smart Card holder

Additional stylus (five pack)

Notebook Guardian Lock

4-in-1 adapter

Firewire adapter

Carrying Cases

- Deluxe Case
- Duo
- Modella Backpack
- Diplomat

Fujitsu Premium Care Service Programs available.

Visit us.fujitsu.com/computers to purchase any of these accessories or to get more information.



Have questions or need help?

- Visit our Web site at us.fujitsu.com/computers
- Call us anytime at 1-877-372-3473
- E-mail us at 8fujitsu@us.fujitsu.com

Record your notebook serial number here:

Serial # _____
(see bottom of computer)

Fujitsu Computer Systems Corporation
1250 E. Arques Avenue M/S 122
Sunnyvale, CA 94085

Fujitsu, the Fujitsu logo, and LifeBook are registered trademarks of Fujitsu Limited. Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries. All other trademarks mentioned herein are the property of their respective owners. Product description data represents Fujitsu design objectives and is provided for comparative purposes; actual results may vary based on a variety of factors. Specifications are subject to change without notice.

©2005 Fujitsu Computer Systems Corporation. All rights reserved. 0s



B6FH-61 71 -01 EN-00

Getting Started

Get Started with your
LifeBook® B Series
Notebook